Rapid Modular Silencing System Mss No More Noise!

The Modular way to a **Silent working environment!**



Controlling NOISE with Rapid Modular Silencing System, Rapid MSS

No More Noise!



The most effective way to reduce noise is to capture it at the source, i.e. prevent it from spreading into the working environment. You can then reduce significantly more dB(A) in a very cost efficient way compared to e.g. noise absorbing panel in the ceiling.

The Rapid MSS (Modular Silencing System) is a concept that can be adapted to any noise generating source in the production plant. As it is capturing the noise at the source it can reduce as much as 10 - 20 dB(A).

Rapid's MSS main area is extra sound protection for granulators and granulator transport systems to reduce operating noise levels and enhance the health and safety regime in the workplace.



The main areas for Rapid MSS is as sound enclosure for granulators and their transport system.

The Rapid MSS's main advantages:

- Absorbs the noise, at the source, preventing noise in the production area.
- Effective lower the noise emission by up to 10 20 dB(A).
- Modular The Rapid MSS is designed as a modular concept and can therefore be added to any granulator configuration. Modular aluminium framework with corresponding noise absorbing silencing modules.
- Flexible Thanks to the easy modular system, with both light weight and easy assembly the MSS can be relocated in no time if changing the production layout.
- **Standardized -** Standard solutions for all Rapid machines available.
- **Easy handling** light weight, easy attachments one person can easily install a standard MSS cabinet in less than two hours.

Understanding noise and its consequences!

The level of the noise that might induce hearing loss depends on the duration of the exposure. Based on a dose-effect assumption the critical level for noise-induced hearing loss is set to 85 dB(A) during 8 hours per day. However, the individual variation in susceptibility is large and even for this dose some subjects are likely to be affected. According to the equal-energy principle an increase by 3 dB would halve the permissible duration. This implies maximum 28 seconds noise exposure at 115 dB(A). For short lasting impulse sounds the peak level, regardless of the total energy, might cause a permanent threshold shift.

Critical noise levels

What are the action levels and limit values?
These relate to the levels of exposure to noise averaged over a working day or week; and the maximum noise (peak sound pressure) to which you are exposed to in a working day.

Duration of noise exposure and the noise level determines the risk of hearing. The critical level for noise related hearing loss is set to 85 dB(A) per 8 hours daily. Individual variations is large and some persons are more likely to be affected than others. According to the equal-energy principle an increase by 3 dB in noise level would halve the duration. And consequently, maximum 28 seconds noise exposure

at 115 dB(A). For short lasting impulse sounds the peak level, regardless of the total energy, might cause a permanent threshold shift.


The values are:

- Lower exposure action values:
 - daily or weekly exposure of 80 dB;
- peak sound pressure of 135 dB;
- upper exposure action values without protection:
 - daily or weekly exposure of 85 dB;
 - peak sound pressure of 137 dB.

There are also levels of noise exposure which must never be exceeded:

exposure limit values:


- daily or weekly exposure of 87 dB;
- peak sound pressure of 140 dB.






Do you know how to minimize noise?

- Stop it from spreading around as close to the source as possible: Contain and capture it!
- Stop it from bouncing around: Stop reflections!
- Rapid RSS does both containing and absorbing!
- The decibel scale is logarithmic,
 A 3-decibel increase in the noise level
 already represents a doubling of the noise
 loudness.
- RSS reduce noise levels by 10 20 dB(A)!



Complete Sound cabinet for granulator



| Granulator model | Art. No | Α | В | С |
|--------------------------|---------|------|------|------|
| Rapid 300-Series, slim* | 9-63200 | 2000 | 2000 | 1600 |
| Rapid 300-Series, wide** | 9-63201 | 3600 | 2400 | 2000 |
| Rapid 400-Series, slim* | 9-63202 | 2000 | 2000 | 1600 |
| Rapid 400-Series, wide** | 9-63203 | 3600 | 2400 | 2000 |
| Rapid 500-Series, slim* | 9-63204 | 2400 | 2400 | 2000 |
| Rapid 500-Series, wide** | 9-63205 | 3200 | 2800 | 2400 |

^{*} No extra space inside. ** Wide enough to get around the granulator.

MSS - Frame-work components

| 9-62969 400 9-62970 800 9-62971 1200 Cross bar, corner L 9-62972 400 9-62973 800 9-62974 1200 2-way-fitting, center 9-62975 Pc: 3-way-fitting, center 9-62976 Pc: 9-62977 | | 4 | | |
|---|---------------------------------------|---------|------|-----|
| 9-62970 800 9-62971 1200 Cross bar, corner L 9-62972 400 9-62973 800 9-62974 1200 2-way-fitting, center 9-62975 3-way-fitting, center 9-62976 9-62977 Pc: 9-62978 3-way-fitting, center, open 9-62978 | Cross bar | Art. No | L | Pcs |
| 9-62971 1200 Cross bar, corner 9-62972 400 9-62973 800 9-62974 1200 2-way-fitting, center 9-62975 2-way-fitting, corner 9-62976 3-way-fitting, center, open 9-62978 Pc: 9-62978 | | | | |
| Cross bar, corner | • | | | |
| 9-62972 400 9-62973 800 9-62974 1200 2-way-fitting, center 9-62975 2-way-fitting, corner 9-62976 3-way-fitting, center, open 9-62978 Pc: 3-way-fitting, center, open 9-62978 Pc: 9-62978 | | 9-62971 | 1200 | |
| 9-62973 800 9-62974 1200 2-way-fitting, center 9-62975 Pc: 9-62976 3-way-fitting, center 9-62977 9-62977 Pc: 9-62978 Pc: 9-62978 | Cross bar, corner | | L | Pcs |
| 2-way-fitting, center 9-62975 2-way-fitting, corner 9-62976 3-way-fitting, center 9-62977 3-way-fitting, center, open 9-62978 Pc: 9-62978 | \mathcal{Q} \mathcal{Q} | 9-62972 | 400 | |
| 2-way-fitting, center 9-62975 2-way-fitting, corner 9-62976 3-way-fitting, center 9-62977 Pc: 9-62978 Pc: 9-62978 Pc: 9-62978 | | 9-62973 | 800 | |
| 2-way-fitting, corner 9-62976 3-way-fitting, center 9-62977 9-62977 Pc: 9-62978 Pc: 9-62978 | e e e e e e e e e e e e e e e e e e e | 9-62974 | 1200 | |
| 2-way-fitting, corner 9-62976 3-way-fitting, center 9-62977 9-62977 Pc: 9-62978 Pc: 9-62978 | 2 way fitting contar | | | Dos |
| 2-way-fitting, corner 9-62976 3-way-fitting, center 9-62977 Pc: 9-62978 Pc: 3-way-fitting, center, open 9-62978 | 2-way-fitting, center | 0-62075 | | 103 |
| 3-way-fitting, center 9-62976 9-62977 3-way-fitting, center, open 9-62978 Pc: 9-62978 Pc: 9-62978 | | 3-02313 | | |
| 3-way-fitting, center 9-62977 3-way-fitting, center, open 9-62978 Pc: 9-62978 Pc: 9-62978 | | | | |
| 3-way-fitting, center 9-62977 3-way-fitting, center, open 9-62978 Pc: 9-62978 Pc: 9-62978 | 2-way-fitting corner | | | Pcs |
| 3-way-fitting, center 9-62977 3-way-fitting, center, open 9-62978 Pc: 9-62978 | 2 way many, corner | 9-62976 | | |
| 3-way-fitting, center, open 9-62978 Pc: 9-62978 Pc: 9-62978 | | | | |
| 3-way-fitting, center, open 9-62978 Pc: 9-62978 Pc: 9-62978 | | | | |
| 3-way-fitting, center, open 9-62978 Pc: 9-62978 Pc: 9-62978 | 3-way-fitting, center | | | Pcs |
| 9-62978 3-way-fitting, corner | 7 | 9-62977 | | |
| 9-62978 3-way-fitting, corner | 115 | | | |
| 9-62978 3-way-fitting, corner | • | | | |
| 9-62978 3-way-fitting, corner | 3-way-fitting center open | | | Pcs |
| 3-way-fitting, corner Pc | way maning, conton, open | 9-62978 | | |
| o may manage or more | | | | |
| o may manage come. | | | | |
| o may manage or more | 0 | | | |
| 9-029/9 | 3-way-titting, corner | 0.00070 | | Pcs |
| | | 9-62979 | | |
| | | | | |

MSS – Frame-work components


Knife Mark pen

| 4-way-fitting, center | Art. No | |
|--|---------------|--|
| | 9-62980 | |
| | | |
| | | |
| A way fitting corner | | |
| 4-way-fitting, corner | 9-62981 | |
| | 0 02001 | |
| | | |
| | | |
| 5-way-fitting | | |
| | 9-62982 | |
| | | |
| • | | |
| 6-way-fitting | | |
| o may many | 9-62983 | |
| | | |
| 40 | | |
| | | |
| Wheel fitting, corner | 0.0004 | |
| | 9-62984 | |
| | | |
| | | |
| Wheel fitting center | | |
| | 9-62985 left | |
| | 9-62986 right | |
| | | |
| I Para | | |
| Hinge | 9-62987 | |
| PA I | 3-02301 | |
| Įų. | | |
| | | |
| Handle | MD | |
| | 9-62988 | |
| | | |
| | | |
| Scrows K6S M/v20 hov 200 nos | 9-63181 | |
| Screws, K6S M4x20, box 200 pcs, (8 screws/cross bar) | 0-00101 | |
| | | |
| Panel customization kit | | |
| Tailored tape | 9-62989 | |

MSS - Sound proofing panels

| Sound proofing panel | | L | W | Pcs |
|---------------------------------------|---------|------|---------|-----|
| | 9-62990 | 400 | 400 | |
| | 9-62991 | 400 | 800 | |
| | 9-62992 | 400 | 1200 | |
| | 9-62993 | 800 | 800 | |
| | 9-62994 | 800 | 1200 | |
| | 9-62995 | 1200 | 1200 | |
| Sound proofing for pipe, straight | | L | Ø | Pcs |
| | 9-62996 | 300 | 100 | |
| | 9-62997 | 1200 | 100 | |
| | 9-62998 | 300 | 160/200 | |
| | 9-62999 | 1200 | 160/200 | |
| Sound proofing, pipe, bend, up to 30° | À | | Ø | Pcs |
| 2 pcs -> 45° | 9-63000 | | 100 | |
| 3 pcs -> 90° | 9-63001 | | 160/200 | |
| | | | | |
| Sound proofing, pipe, conversion | 9-63002 | | | Pcs |
| Ø 100 mm <-> Ø 160/200 mm | | | | |
| 2 100 11111 1 7 2 100,200 11111 | | | | |
| | | | | |

Predesigned cabinets for granulator




| Artricle | Pcs |
|------------------------------|-----|
| Sound proofing, 400x800 mm | 8 |
| Sound proofing, 400x1200 mm | 4 |
| Sound proofing, 800x800 mm | 4 |
| 2-way-fitting, corner | 4 |
| 3-way-fitting, center | 12 |
| 3-way-fitting, corner | 12 |
| 4-way-fitting, center | 4 |
| 4-way-fitting, corner | 8 |
| Crossbar, 400 mm | 12 |
| Crossbar, 800 mm | 20 |
| Crossbar, 1200 mm | 14 |
| Crossbar, corner, 400 mm | 4 |
| Crossbar, corner, 800 mm | 8 |
| Crossbar, corner, 1200 mm | 6 |
| Wheel fitting, corner | 4 |
| Wheel fitting, right | 2 |
| Wheel fitting, left | 2 |
| K6S M6x16 FZB, box à 200 pcs | 3 |
| Panel customization kit | 1 |
| | |

Rapid MSS – Easy to fit

Assembly procedure guidelines


- Assemble the frame work laying flat on the floor, when completed, raise each section up. Start with the main wall.
- Assemble each "layer" in the frame work before fitting it together.
- Leave all screws loose until fitting is complete.
- Flexible Thanks to easy modular system, with both light weight and easy assembly the MSS can be relocated in no time if changing the production layout.
- Inlet With the "Panel Customization Kit" it's easy to cut a "window" in a panel for e.g. belt conveyor etc, see right.



Panel customization kit - instructions for belt conveyor inlet-window










To make access to the MSS-enclosure, i.e. an opening for a belt conveyor, just measure and cut the opening accordingly. Then seal the plane of sections with the tailored tape.

Rapid Modular Silencing System



| Eav this | orderform | to 1/16 | 270 | 202E1 |
|------------|-----------|----------|-----|-------|
| rax unis (| uruentum | I LO +40 | 3/0 | DULDI |

| Your name: | |
|------------|------------|
| Company: | Telephone: |
| Country: | Email: |

| Part | Art.No | Pcs |
|-------------------------------------|---------|-----|
| Complete cabinet, Rapid 300 | 9-63200 | |
| Complete cabinet, Rapid 300-wide | 9-63201 | |
| Complete cabinet, Rapid 400- | 9-63202 | |
| Complete cabinet, Rapid 400-wide | 9-63203 | |
| Complete cabinet, Rapid 500- | 9-63204 | |
| Complete cabinet, Rapid 500-wide | 9-63205 | |
| Cross bar, 400 mm | 9-62969 | |
| Cross bar, 800 mm | 9-62970 | |
| Cross bar, 1200 mm | 9-62971 | |
| Cross bar, corner, 400 mm | 9-62972 | |
| Cross bar, corner, 800 mm | 9-62973 | |
| Cross bar, corner, 1200 mm | 9-62974 | |
| 2-way fitting, center | 9-62975 | |
| 2-way fitting, corner | 9-62976 | |
| 3-way fitting, center | 9-62977 | |
| 3-way fitting, center, open profile | 9-62978 | |
| 3-way fitting, corner | 9-62979 | |
| 4-way fitting, center | 9-62980 | |
| 4-way fitting, corner | 9-62981 | |
| 5-way fitting | 9-62982 | |
| 6-way fitting | 9-62983 | |

| Part | Art.No | Pcs |
|--|---------|-----|
| Wheel fitting, corner | 9-62984 | |
| Wheel fitting, center - left | 9-62985 | |
| Wheel fitting, center - right | 9-62986 | |
| Hinge | 9-62987 | |
| Handle | 9-62988 | |
| Screws, K6S M4x20, box 200 pcs, 8/cross bar | 9-63181 | |
| Panel customisation kit | 9-62989 | |
| Sound proofing, 400 x 400 mm | 9-62990 | |
| Sound proofing, 400 x 800 mm | 9-62991 | |
| Sound proofing, 400 x 1200 mm | 9-62992 | |
| Sound proofing, 800 x 800 mm | 9-62993 | |
| Sound proofing, 800 x 1200 mm | 9-62994 | |
| Sound proofing, 1200 x 1200 mm | 9-62995 | |
| Sound proofing, pipe Ø100 mm, 300 mm | 9-62996 | |
| Sound proofing, pipe Ø100 mm, 1200 mm | 9-62997 | |
| Sound proofing, pipe Ø160/200 mm, 300 mm | 9-62998 | |
| Sound proofing, pipe Ø160/200 mm, 1200 mm | 9-62999 | |
| Sound proofing, pipe Ø100 mm, bend 30° | 9-63000 | |
| Sound proofing, pipe Ø160/200 mm, bend 30° | 9-63001 | |
| Sound proofing, pipe, conversion Ø 100 – 160/200 mm, | 9-63002 | |



Rapid Granulator AB - Head Office

Box 9, Industrivägen 4 SE-330 10 Bredaryd, Sweden Phone: +46 370 86500 Fax: +46 370 80251

Fax: +46 370 80251 Email: info@rapidgranulator.se

Rapid worldwide:

USA info@rapidgranulator.com Germany info@rapidgranulator.de Italy info@rapidgranulator.it China info@rapidgranulator.cn Singapore rapidsea@pacific.net.sg